



DO'S & DON'TS FOR YOUR HOBART DISHWASHER

DO'S

- DO** assure proper water hardness of 3 grains or less per gallon.
- DO** pre-scrub dishes thoroughly.
- DO** use only detergents recommended by your chemical professional.
- DO** at the end of the day, complete a manual cleaning cycle as needed; thoroughly cleanse the machine, rinse, and dry (leave doors open).
- DO** at the end of each meal period, complete an Auto Clean cycle (when equipped), following instructions on the display.
- DO** use only products formulated to be safe on stainless steel.

DON'TS

- DO NOT** use detergents formulated for residential dishwashers.
- DO NOT** allow food soil to accumulate on the tank bottom.
- DO NOT** use steel wool to clean ware or dishwasher surface.
- DO NOT** allow foreign objects to enter the unit, especially metallic contaminants.

NOTE: Failure to follow use, care, and maintenance instructions may void your Hobart dishwasher warranty.